

Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

# DGA - Method in the Past and for the Future

IVANKA ATANASOVA-HÖHLEIN



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

SIEMENS

VOL. XXVII NO. 442

MAY 1956

THE METROPOLITAN-VICKERS GAZETTE

CONTENTS

PAGE

Frontispiece: Transformers for a C.E.A. power station	
The identity and significance of gases collected in Buchholz protectors V. H. HOWE, L. MASSEY & A. C. M. WILSON ..	139
A new signalling installation at Posters Bar (British Railways) H. C. TOWERS .. .. .	149
The electrical equipment of a Scottish cotton mill J. W. JACKSON .. .. .	153
A polarity tester for high-power magnets J. W. WALLBY .. .. .	157
The preparation of uniform plastic films R. S. M. REVELL & A. W. AGAR .. .. .	159
Replica techniques in electron microscopy A. W. AGAR & R. S. M. REVELL .. .. .	163
Design progress 7: Automatic power-factor correction equipment .. .. .	164
Notes and news: Metrovick products on view at the British Industries Fair—More generating plant for Hong Kong—The Factory Equipment Exhibition—A miniature oscilloscope .. .. .	167

The identity and significance of gases  
collected in Buchholz protectors

V. H. HOWE A.M.I.E.E., ASSOC.M.C.T.


L. MASSEY M.Sc.TECH., A.B.I.C.

A. C. M. WILSON ASSOC.M.C.T.

- 1970 – Doerenburg introduced the differentiation between electrical and thermal failure mode and introduced ratios for fault gases with similar solubility.
- 1973 – Halstead developed the theoretical thermodynamic theory. The ratios are temperature dependent. With increasing the hotspot the amount of gases increases in the order: methane-ethane-ethylene.
- 1975 – The evaluation scheme of the modern Gas-in-Oil Analysis is developed by Rogers, Mueller, Schliesing, Soldner (MSS)..
- 1995- Development of In-Line Monitoring

Different phenomena in oil take place like:

dielectric  
thermal  
dynamic  
chemical



Change/Ageing

- **Gas-in-Oil Analysis (DGA = Dissolved Gas Analysis)**

**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**

**SIEMENS**

The measurement of dissolved gases allow the knowledge on

**Type  
Complexity  
Seriousness**

of event.

**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**

**SIEMENS**

# **Sampling**

## **SAMPLING CONTAINER**



- ✓ **Perfectly cleaned & Dried**
- ✓ **Free from dust & moisture**
- ✓ **Airtight**
- ✓ **Glass or Metal cans, syringes**



- ✓ **Protect sample from direct light**
- ✓ **Avoid moisture & dust contamination**
- ✓ **Use the sampling containers exclusively for transformer oil sampling**

# Diagnostic Conference, Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**



- 1 Handwheel
- 2 Sealing cap
- 3 Safety chain
- 4 Polyamid gasket
- 5 Nut
- 6 Drain valve
- 7 Hose and screw connector
- 8 Sampling bottle
- 9 Overflow vessel



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

SIEMENS



# Diagnostic Conference, Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009



## Required information concerning oil sample(example)

**Requested analysis:**

Colour	ISO 2049	<input type="checkbox"/>
Appearance	IEC 60422	<input type="checkbox"/>
Neutralisation value	IEC 62021-1	<input type="checkbox"/>
Breakdown voltage	IEC 60156	<input type="checkbox"/>
Water content	IEC 60814	<input type="checkbox"/>
Loss factor at 50 Hz	IEC 60247	<input type="checkbox"/>
Interfacial tension	ISO 6295	<input type="checkbox"/>
PCB-content	EN 12766-2	<input type="checkbox"/>
Furananalysis (DGA)	IEC 61198	<input type="checkbox"/>
Gas-in-oil-analysis	IEC 60567	<input type="checkbox"/>
		<input type="checkbox"/>
		<input type="checkbox"/>

**Please fill in the following data:**

Manufacturer:	FTNR (Manufacturing No.):			
Customer:	WNR (Order No.):			
Location:	Sample No.:			
Year of manufacture:	Date sample taken.:			
Type:	Type of oil			
Power:	Quantity of oil:			
Rating:	<b>Oil temperature in the sample taken:</b>			
<p><b>Sample taken from:</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> Oil sample valve</td> <td style="width: 33%;"><input type="checkbox"/> Oil drainage device A 22/31/40 DIN 42 551</td> <td style="width: 33%;"><input type="checkbox"/> Others</td> </tr> </table>		<input type="checkbox"/> Oil sample valve	<input type="checkbox"/> Oil drainage device A 22/31/40 DIN 42 551	<input type="checkbox"/> Others
<input type="checkbox"/> Oil sample valve	<input type="checkbox"/> Oil drainage device A 22/31/40 DIN 42 551	<input type="checkbox"/> Others		
<p><b>Tank:</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> Top</td> <td style="width: 33%;"><input type="checkbox"/> Middle</td> <td style="width: 33%;"><input type="checkbox"/> Bottom</td> </tr> </table>		<input type="checkbox"/> Top	<input type="checkbox"/> Middle	<input type="checkbox"/> Bottom
<input type="checkbox"/> Top	<input type="checkbox"/> Middle	<input type="checkbox"/> Bottom		
<p><b>conservator</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> Transformer</td> <td style="width: 33%;"><input type="checkbox"/> OLTC</td> <td style="width: 33%;"><input type="checkbox"/> Bushing</td> </tr> </table>		<input type="checkbox"/> Transformer	<input type="checkbox"/> OLTC	<input type="checkbox"/> Bushing
<input type="checkbox"/> Transformer	<input type="checkbox"/> OLTC	<input type="checkbox"/> Bushing		
<p><b>OLTC</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> OLTC tank</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> </tr> </table>		<input type="checkbox"/> OLTC tank	<input type="checkbox"/> _____	<input type="checkbox"/> _____
<input type="checkbox"/> OLTC tank	<input type="checkbox"/> _____	<input type="checkbox"/> _____		
<p><b>Bushing</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> _____</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> </tr> </table>		<input type="checkbox"/> _____	<input type="checkbox"/> _____	<input type="checkbox"/> _____
<input type="checkbox"/> _____	<input type="checkbox"/> _____	<input type="checkbox"/> _____		
<p><b>Others:</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><input type="checkbox"/> _____</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> <td style="width: 33%;"><input type="checkbox"/> _____</td> </tr> </table>		<input type="checkbox"/> _____	<input type="checkbox"/> _____	<input type="checkbox"/> _____
<input type="checkbox"/> _____	<input type="checkbox"/> _____	<input type="checkbox"/> _____		

**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**


**SIEMENS**

## **Extraction of Gases from the Oil**

Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

## DGA. Toepler Pump



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

## DGA. Partial Degassing



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

## DGA. Headspace at Ambient Temperature



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

## DGA. Headspace at 70°C




**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**

**SIEMENS**


**Gaschromatographic  
Analysis**



## Gaschromatographic Analysis




- **Partial discharges**
- **Electrical discharges**
- **Charcoal coating of contacts**
- **Accelerated cellulosic degradation**
- **Local overheating**
- **Untightness of OLTC tank**
- **Catalytic reactions of materials**
- **Additional information from BHR gas**



Failures which  
can be identified  
by DGA

- **Incipient Failures**
- **Long lasting temperatures < 150 °C**



Failures which  
can not be  
identified by DGA

**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**


**SIEMENS**

## **Interpretation Schemes**

Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009


SIEMENS

Duvals  
Triangle




Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009


SIEMENS



**Electrical Discharges**



**Partial Discharges**



**Thermal Problem**

**Patterns**

## MSS Scheme

Ratio ranges	Ratio numbers				
	$\frac{[C_2H_2]}{[C_2H_6]}$	$\frac{[H_2]}{[CH_4]}$	$\frac{[C_2H_4]}{[C_2H_6]}$	$\frac{[C_2H_4]}{[C_3H_6]}$	$\frac{[CO_2]}{[CO]}$
< 0.3	0	0	0	0	1
0.3 to < 1.0	1	0	0	1	1
1.0 to < 3.0	1	1	1	2	1
3.0 to < 10.0	2	2	1	3	0
≥ 10.0	2	3	1	3	2
Diagnosis	Number sequences				
Normal ageing of insulants	0	0	0	0	0
Discharge of high energy	2	1	1	2/3	1
Discharge of low energy	2	2	1	2/3	1
Partial discharge with high energy	1	3	0	n.i.	0
Partial discharge with low energy	0	3	0	n.i.	0
Local overheating up to 300 °C	0	0	0	1	2
Local overheating from 300 to 1000 °C	0	0	1	2	2
Local overheating over 1000 °C	1	0	1	2/3	2
Local overheating and discharge	1	1	1	2	2
Local overheating and partial discharge	0	3	1	2	2

n.i. = not indicative

## IEC Scheme

Case	Characteristic fault	$\frac{C_2H_2}{C_2H_6}$	$\frac{CH_4}{H_2}$	$\frac{C_2H_4}{C_2H_6}$
PD	Partial discharges (see notes 3 and 4)	NS <sup>1)</sup>	<0,1	<0,2
D1	Discharges of low energy	>1	0,1 – 0,5	>1
D2	Discharges of high energy	0,5 – 2,5	0,1 – 1	>2
T1	Thermal fault $t < 300 \text{ }^\circ\text{C}$	NS <sup>1)</sup>	>1 but NS <sup>1)</sup>	<1
T2	Thermal fault $300 \text{ }^\circ\text{C} < t < 700 \text{ }^\circ\text{C}$	<0,1	>1	1 – 4
T3	Thermal fault $t > 700 \text{ }^\circ\text{C}$	<0,2 <sup>2)</sup>	>1	>4

NOTE 1 In some countries, the ratio  $C_2H_2/C_2H_6$  is used, rather than the ratio  $CH_4/H_2$ . Also in some countries, slightly different ratio limits are used.

NOTE 2 The above ratios are significant and should be calculated only if at least one of the gases is at a concentration and a rate of gas increase above typical values (see clause 9).

NOTE 3  $CH_4/H_2 < 0,2$  for partial discharges in instrument transformers.

$CH_4/H_2 < 0,07$  for partial discharges in bushings.

NOTE 4 Gas decomposition patterns similar to partial discharges have been reported as a result of the decomposition of thin oil film between overheated core laminates at temperatures of 140 °C and above (see 4.3 and [1] of annex C).

<sup>1)</sup> NS = Non-significant whatever the value.

<sup>2)</sup> An increasing value of the amount of  $C_2H_2$  may indicate that the hot spot temperature is higher than 1 000 °C.

In case of quotient formation it must be clear, that quotients are only representative, if following values of the fault gases (in ppm) are exceeded:

C <sub>2</sub> H <sub>2</sub>	≥ 1
H <sub>2</sub>	≥ 15
Σ [C <sub>x</sub> H <sub>y</sub> ] x=1;2;3	≥ 50
CO	≥ 80
CO <sub>2</sub>	≥ 200

## DGA. Example – thermal Problem

MSS-Code 00120

Fault gas	ppm
Hydrogen	1967
Methane	8008
Ethane	2013
Ethylene	8323
Acetylene	57
Propane	401
Propylene	4824
Carbon monoxide	253
Carbon dioxide	1903
Oxygen	18222
Nitrogen	61662



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

SIEMENS

**360 MVA, Manufacturing year 1970**

Carbon deposits on OLTC Contacts, **MSS Code  
00120**

Fault gas	ppm
Hydrogen	537
Methane	1041
Ethane	295
Ethylene	1726
Acetylene	25
Propane	83
Propylene	1012
Carbon monoxide	1047
Carbon dioxide	6158
Oxygen	11805
Nitrogen	58084



## Gas-in-Oil Analysis. Turn-to-Turn Fault

MSS Code 21121

	Fault gas	ppm
H <sub>2</sub>	Hydrogen	4973
CH <sub>4</sub>	Methane	1758
C <sub>2</sub> H <sub>6</sub>	Ethan	243
C <sub>2</sub> H <sub>4</sub>	Ethylene	2813
C <sub>2</sub> H <sub>2</sub>	Acetylene	8236
C <sub>3</sub> H <sub>8</sub>	Propane	58
C <sub>3</sub> H <sub>6</sub>	Propylene	1320
CO	Carbon Monoxide	1196
CO <sub>2</sub>	Carbon Dioxide	2431
O <sub>2</sub>	Oxygen	6743
N <sub>2</sub>	Nitrogen	44120



Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

**SIEMENS**

## DGA. Thermal Problem with Partial Discharges

234 MVA, 330 kV, Manufacturing year 1991

Defective welding joint

**MSS 00101**

Hydrogen	1060
Methane	2481
Ethane	703
Ethylene	2187
Acetylene	4
Carbon monoxide	450
Carbon dioxide	995



## DGA. Catalytical Effects


Manufacturing year 1977, closed type, MSS Code  
?3??0, color 0,5, acidity 0,01

Hydrogen	488
Methane	1
Ethane	< 1
Ethylene	< 1
Acetylene	< 1
Propane	< 1
Propylene	< 1
Carbon monoxide	67
Carbon dioxide	222
Oxygen	5180
Nitrogen	23700


## DGA. Untight OLTC

MSS 22122

Fault gas	ppm
Hydrogen	128
Methan	25
Ethane	5
Ethylene	81
Acetylene	288
Propane	5
Propylene	50
Carbon monoxide	143
Carbon dioxide	1920
Oxygen	24600
Nirogen	52000



## Diagnostic Importance in Service. DGA



## Absolute Values

### IEC 60599 (VDE 0370-7)


	$C_2H_2$	$H_2$	$CH_4$	$C_2H_4$	$C_2H_6$	CO	$CO_2$
All transformers		50 - 150	30 - 130	60 - 280	20 - 90	400 - 600	3 800 - 14 000
No OLTC	2 - 20						
Communicating OLTC	60 - 280						

## Ratios

- a) Eliminates the effect of the oil volume
- b) Eliminates some effects of sampling
- c) Especially interesting is the ratio formation for fault gases which exhibit similar solubilities, but their development is temperature dependent – e. g. the thermodynamic considerations of Halstead.

Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

SIEMENS



Thermodynamical considerations of Halstead


## Gas Increase Rates – information on seriousness of failure

	$C_2H_2$	$H_2$	$CH_4$	$C_2H_4$	$C_2H_6$	CO	$CO_2$
All transformers	0,01	0,36	0,33	0,40	0,25	2,9	27



**90% gas increase rates source: Cigre TF11 in ppm/day**

Gas increase rates are temperature- and volume dependent.

# TRENDANALYSIS



# Diagnostic Conference, Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009



Trendanalysis is important not only with absolute values, but also with the ratios.

## **On-Line Monitoring**

- Early failure recognition
- Diagnosis is only possible with the sophisticated types – where IEC ratios can be built

Cigre TF 15 DGA did a comparison between On-Line monitoring systems and Off-Line analyses. The brochure is on the way. Evaluated are:

- Precision
- Longterm stability
- Repeatability

In case of

Routine concentrations, d.h. 5 \* Detection Limit

Low Concentrations, d. h. 2-5\*Detection Limit

## RECOMMENDATION OF CIGRE A2.27 FOR ON-LINE MONITORING

- Necessary in case a problem has been identified
- Often, however, difficult to maintain
- Interfaces can lead to problems
- Able to deliver important information in a short time
- Does not automatically lead to higher reliability

**What can be measured on-line:**

**Temperature**

**Current, Voltage**

**OLTC**

**Oil level**

**Gas-in-Öl Analysis**

**Humidity in oil**

**Bushings**

**Acoustic Signals**


**Magnetic Circuit**


**Coolers**

Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009

SIEMENS

MORE DATA DOES NOT MEAN AUTOMATICALLY MORE  
INFORMATION





### Transformer Failure Rate

A: Failure at commissioning; B: constant failure rate; C: failure because of ageing

## **DGA - Method in the Past and for the Future**

### **Future Developments**

**Further development of the On-Line analysis with decision criteria**

**Gas-in-oil analysis in OLTC**

**Gas-in-oil analysis in alternative insulation fluids and high temperature insulating materials**

**Diagnostic Conference,  
Siofok, Hungary, October 14<sup>th</sup>-16<sup>th</sup> 2009**

**SIEMENS**

**THANK YOU FOR YOUR ATTENTION**

